


INSTALLATION GUIDE MODEL NO. EOL-WL10FR-3100se

LED Fixtures Outdoor Wall Light Series Half Cylinder Class



Questions?

For customer service please call us at 1-310-787-1100 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday E-mail: hello@euricompany.com



LED 6 CCT Half Cylinder Wall Sconce

PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION


WARNINGS

- · Risk of fire / electrical shock
- LED Fixture installation requires knowledge of luminaire electrical systems.
- Risk of electric shock disconnect power at source before installation
- Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove lamp and contact us. For more information please visit www.euricompany.com or email hello@euricompany.com


CAUTIONS

- Do not use with dimmers.
- Do not look directly at the operating LED Tube.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter lamp.
- Designed for indoor applications only.
- Suitable for wet locations.
- The luminaires shall be grounded.
- Be careful not to touch the lamp pins to the metal housing when installing.
- This Device is not intended for use with emergency exits or emergency lights.


INSTALLATION INSTRUCTIONS




1. Remove the backplate.



2. Install the mounting plate onto the junction box(not included).




3. Connect the wires, attach the backplate, and tighten the nuts.



4. Apply glue or waterproof silicone near the backplate. Done.

USE THE SENSOR COVER




1.The light will turn on at dusk and remain on through the night until dawn. The light will remain off throughout the day, until dusk.

2.At this time if the light is strong, please cover the sensor cover, after 15 seconds the light is on, then the installation is correct.

NOTE: NOTE: If you want to use the DUSK TO DAWN function, please remove the sensor cover. After commissioning the fixture is completed.

CCT SELECT SWITCH



Choose your preferred color temperature between 2700K, 3000K, 3500K, 4000K, 5000K, and 6500K with switch.